



# INSTALL SHEET

## CLRBD15-REAR BUMPER

### 2015+ COLORADO/CANYON

#### PLEASE NOTE:

This install Guide describes the process for installing the CLRBD15 Rear Bumper with and without the Dual Exhaust Option.

#### PACKAGE CONTAINS



#### Components:

D - Rear Bumper

E - Dual Exhaust Plumbing

#### Tools Needed:

3/16" Wrench

Phillips Screwdriver

\* Save and use all original fasteners.

#### HARDWARE

A - 1/4" Phillips Screw

(2)



B - 3/8" Lock Nut

(2)



C - 3/8" U Bolt

(1)



1

Remove the wiring from the original bumper.

2

Remove the original bumper from the vehicle. There are two fasteners per side. Save these to install your new bumper.

3

Remove the license plate light mounts and tow light harness plug from the old bumper and reinstall them on the new bumper. (fastener A)

4

DUAL EXHAUST ONLY  
Cut the stock exhaust behind the rear wheel towards the back of the vehicle. Make sure the cut is 2 inches back from the last hanger.



5

Run the plumbing into position and tighten the clamp on the new joint.



6

Install the new bumper at the original bumper position. Be sure that the spare tire tube is aligned appropriately.



7

Install the U-bolt over the exhaust plumbing and secure the lock nuts into place. Connect lights and tow light harness plugs.



8

If you purchased the optional exhaust tips fit them to the tail pipe and tighten the fastener.

**Go back and fully tighten all fasteners. Check them periodically.**

