



INSTALL SHEET

M1 REAR BUMPER

2018 JEEP WRANGLER JL

JLRB18, JLRBL18, JLRBR18, JLRBRL18

VIDEO GUIDES:
WWW.MCAFTERMARKET.COM/INSTALL

PACKAGE CONTAINS

Components:
Mirror "Elbows" (2)
Mirrors (2)
Bolts (2)
Washers (2)

3/4" Wrench (not included)
T50 Torx Socket Extension
(not included)



SERVICE AND SUPPORT **CONTACT**

Motor City Aftermarket

734-525-9030

sales@mcaftermarket.com

www.mcaftermarket.com

1

Using medium strength, blue threadlocker, attach the mirror to the elbow. Remove factory windshield hinge bolt using a T50 torx socket and 6" extension.

2

Insert the threaded side of the elbow and turn the entire assembly until it's barely snug. You can back it out a turn to get it into position. Use the next step to lock into place.

3

Use a $\frac{3}{4}$ " wrench to tighten the nut up against the hinge. This will "lock" the mirror into place.

